

Wireless Access Point on Jetson TX2

This Document is for the guidance to create Jetson TX2 as a stand alone Wireless Access Point (WAP).


Step:1Click on the *Connections* icon on top right of the desktop, then select the *Edit Connections*.



Step:2Upon clicking the *Edit Connections* option a below window will be opened.




Click on *Wi-Fi* option, then below window will opened.




Select the *Wi-Fi* option in the drop down box, and then click on create.

Step: 3Then the below window will be opened.



Enter the *Connection name* as your interest, and navigate to *Wi-Fi* tab.



Enter the

SSID: as your interest,

Mode: select the *Hotspot* in the drop down,

Band: Select **B/G (2.4 Ghz)** option in the drop down,


Channel: default,

Device: Select from the drop down.

Rest leave as it is.

Then go-to **Wi-Fi Security** tab.

Note: Ad-hoc mode is not available on TX2, be careful while selecting the mode as TX2 will turn-off if Ad-hoc mode is selected.



Security: Select **WPA & WPA2 Personal**

Password: As your interest

Rest all the tabs leave as it is.

